
ITEM# 35-780 PRODUCT INSTRUCTION

iGAGING Digital Wheel Marking Gauge + Height Gauge + Depth Gauge 3-in-1



Description

Measure Range: 0-6" / 0-150mm Accuracy: 0.001" per 6 inch Repeatability: 0.0005"

Reading: 0.0005"/ 0.01mm/ inch fraction

Battery: 3V CR2032







Operating:

- Set Zero:
 - 1. Set the Gauge vertically against a flat surface;
 - 2. Aline the Marking Wheel and Fence on the same surface
 - 3. Press Zero button to set zero
- Measure unit: Press Unit Switch to switch between inch, mm, or inch fractional
- Make measurement: loose the Locking Screw and slide the digital display unit until it displays the desirable value.
- Marking: Tighten the Locking Screw at the desired position; make sure the Fence is tightly against the marking surface; slide the gauge to make marking.
- Measure Height or Depth: Set Zero (see above); make height or depth measurement depending on the application.

For More Product Information: www.iGAGING.com © iGaing 2013; San Clemente, California

ITEM# 35-780 PRODUCT INSTRUCTION

iGAGING Digital Wheel Marking Gauge + Height Gauge + Depth Gauge 3-in-1



Description

Measure Range: 0-6" / 0-150mm Accuracy: 0.001" per 6 inch Repeatability: 0.0005"

Reading: 0.0005"/ 0.01mm/ inch fraction

Battery: 3V CR2032

Operating:

- Set Zero:
 - 1. Set the Gauge vertically against a flat surface;
 - 2. Aline the Marking Wheel and Fence on the same surface
 - 3. Press Zero button to set zero
- Measure unit: Press Unit Switch to switch between inch, mm, or inch fractional

Height Gauge

- Make measurement: loose the Locking Screw and slide the digital display unit until it displays the desirable value.
- Marking: Tighten the Locking Screw at the desired position; make sure the Fence is tightly against the marking surface; slide the gauge to make marking.
- Measure Height or Depth: Set Zero (see above); make height or depth measurement depending on the application.

