

Please read through this owners manual carefully before using your new tool. Use your tools properly and only for its intended use.



**ELECTRONIC INDICATOR WITH FRACTIONS**

**I. Features**

1. ON/OFF
2. Floating ZERO
3. Absolute/Incremental readings
4. Direct mm/in/fraction conversion
5. Hold
6. Battery cover
7. Lug back and 3/8 stem diameter
8. Top lifting knob
9. 4-48 contact point (reversible with top lifting knob)



**II. Operation**

1. To turn the indicator on or off press ON/OFF (1) momentarily.
2. To ZERO the indicator at any location press ZERO (2). This can be used in either ABS or INC.
3. Press mm/in/F (4) to display readings in either inch, metric or fraction.
4. Press ABS/INC (3) to toggle between Absolute and Incremental reading. ZERO may be set at any location in either mode.

Specifications	
Measuring Range:	0-1" /0.25mm
Reading:	0.0005"/0.01mm/ 1/128th
Accuracy:	0.001"/0.03mm
• Repeatability:	0.0005"/0.01mm
• Display:	LCD (11.0 mm high)
• Maximum Measuring Speed:	1.5m per second
• Battery:	3V, type CR2032 Lithium
• Battery Life:	Approx. 1 year

**III. Maintenance**

- Avoid contact with liquids and excessive humidity.
- If the instrument requires cleaning, use only isopropyl alcohol and a soft cloth.
- Battery is low when the display flashes. To replace the battery, use a small screwdriver to open the side battery compartment (6). Uses 1 CR2032 battery.