




MiniMag Height Gauge Instruction



1. Base
2. Measuring scribe
3. Battery Compartment
4. SPC Data output
5. LCD Display
6. Column
7. Control Panel

Main Technical Index

Measuring Range: 0-6"/0-150mm

Reading: 0.0005"/0.01mm/1/128"

Accuracy: 0.001"

High Measuring Speed: 120"/second

IP54: Splash water, oil and dust resistant.

Function

ON/OFF key

in/mm/F key: metric/inch/fraction conversion

ABS key: absolute measuring and incremental measuring. Press ABS key to get relative zero. Press the key again, back to normal measuring function.

Hold key: Press the key, the display will not change although the processor is still operation. Press the key again to disable the function and display will show the current reading.

Zero key: Press the key to zero setting at any position.

SPC Data output: Connect data to computer. Purchase separately (Kit included: RS232C USB interface, cable, and software. Item# 35-777).

Power Source

One CR2032, 3V lithium battery can provide up to one year of normal use. The display will flash when a new battery is needed.

Notes

Keep the tool clean

Avoid shocks or accuracy may be affected.

Move the tool by the base, not the column.

For more information, please go to www.iGaging.com.